



1/11




FIG. 1

2/11




FIG. 2

3/11




FIG. 3

4/11




FIG. 4

5/11




FIG. 5

6/11




FIG. 6

7/11




FIG. 7

8/11





FIG. 8

9/11

FIG. 9



10/11

The screenshot shows a window titled "DEVICE CONFIGURATION" with a standard Windows-style title bar (minimize, maximize, close buttons). The main content area is titled "VALVE MANIFOLD BOX". It contains the following fields and controls:

- MODEL:** A dropdown menu currently showing "VALVE_4".
- STATIC/DYNAMIC:** Two radio buttons. "STATIC" is selected.
- IP ADDRESS:** A text box containing "192, 168, 7, 200".
- NAME:** A text box containing "VMB225".
- LOCATION ROOM:** A text box containing "8".
- GRID:** Two adjacent text boxes containing "12" and "18".
- ALARMS ACTIVE:** A label followed by two checked checkboxes: "DOOR OPEN" and "LEAK".

FIG. 10

The screenshot shows a window titled "VALVE CONFIGURATION" with a standard Windows-style title bar. The main content area contains the following fields and controls:

- NAME:** A text box containing "VALVE_HF_1".
- CHEMICAL:** A text box containing "HF".
- INLET CONNECTED TO:** A text box containing "VMB206/VALVE_HF_3/OUT".
- OUTLET CONNECTED TO:** A text box containing "TOOL 18/INLET_HF".

At the bottom of the window, there are two buttons: "PREV" and "NEXT".

FIG. 11

11/11

FIG. 12

